ULTRASONIC GAS MODULE US-100-5V



ULTRASONIC GAS MODULE US-100-5V

US-100-5V is gas analyzer with ultrasonic sensor for detecting. This gas module output analog voltage by measuring sound-speed and temperature of mixed two sorts of gases.

STRONG POINT

- ◎ LONG LIFE
- ◎ EASY TO INSTALLATION
- ◎ ONLY 10 SECOND FOR WARM-UP
- ◎ SAVE ENERGY

SPECIFICATIONS

WARM-UP TIME	About 10 sec.		
SAMPLE TEMP.	Normal temperature (40°Cmax)		
SAMPLE PRESSURE	0∼+5kPa		
FLOW RATE	0.5~5.0L/min		
POWER SUPPLY	Less than \pm 0.1V of DC +5.0V		
AMBIENT TEMP.	5∼45°C		
PIPING	IN OUT :tube of ϕ 5 \sim 6.5 mm		
	in inside diameter		
ANALOG OUTPUT	D. C. 0–1V		
LINEARITY	Less than $\pm 2\%$ of full scale		
REPEATABILITY	Less than $\pm 2\%$ of full scale		
RESPONSE TIME	90% reading is within 10sec.		

PERFORMANCE

	MEASUREMENT	MEASUREMENT
	RANGE	ACCURACY
H2/N2	0~ 50%	0.1%
He/N2、He/Air	0~ 50%	0.1%
02/N2	0 ~ 100%	0.7%
Xe/Ar、Kr/N2、CF4/N2	0 ~ 100%	0.05%
Xe/N2、SF6/N2	0 ~ 100%	0. 03%

%As is often the case with changing this specification for improvement without permission. It is theoretically possible for US-100-5V to analyze some mixed two sorts of gases.

PRINCIPLE & DIMENSION

PRINCIPLE

Sound speed what carries in the gases depends on molecular weight of gas. ULTRASONIC SENSOR calculates average molecular weight that is changed by concentration and temperature of mixed gas, and indicates concentration of mixed two sorts of gases.


RECEIVER

Sound speed goes as follows.


$$V = \sqrt{(\gamma \times R \times T \div M)}$$

where

- γ is the ratio of heat capacity at constant volume to heat capacity at constant pressure
- R is constant of gas (8.314)
- T is Absolute temperature of gas
- M is average molecular weight of mixed gas







TASHIKA BOEKI SHOKAI K.K.

1-12, Kaiyo-cho, Ashiya, 659-0035, JAPAN Tel: + 81-797-23-9035 Fax: + 81-797-23-2105 e-mail: sales@tashika.co.jp URL: www.tashika.co.jp